


Roxy dining chair

OUTDOOR

Product

Specifications

Code	
Sizes (cm)	Total height: 85 Width: 65 Seat height: 45 Depth: 62
Description	The Roxy dining chair is an outdoor dining chair in synthetic rattan with a bold and graphic look. Fit for all weather conditions.
Upholstery	Polyethylene wicker
Glides	Adjustable and tilting nylon glide
Frame	Seat: aluminum frame base: hot dip galvanized and black powder c
Maintenance	A quick wash with a non-foaming mild detergent every three months, will do the trick. A soft nylon brush or a low pressure air hose can also be used to clean between the weaving.
Quality	Recyclable resin (HDPE)



Weather instructions



Colours & fabrics

- Black | Camel